



Check out our install video here—>



Terrawagen Tidy Trim Kit Front

TWNS-48

Installation instructions and contents:

Thanks for buying Terrawagen products! This kit is specifically designed for 2019 and newer Sprinter High Roof models. Pieces are designed to interlock and be covered with fabric, some sanding and fitting may be required.

Kit contents: 7 piece front trim segments, hardware pack, Jelly beans

Threaded standoffs are for the upper slider door segment. Thread standoffs over existing sprinter upper track studs. Foam blocks have an adhesive strip and are designed to keep the slider door segment pushed against the slider door rubber seal. See figure 1 for standoff configuration and foam block location. Push segments into the factory seal at perforation firmly to lock into correct positions. “C” Pillar segments and window surround attach with supplied self tapping screws.



1. Window Surround
2. Headliner Void Driver Side
3. Headliner Void Passenger Side
4. Slider Door Upper
5. C Pillar Upper
6. C Pillar Lower
7. C Pillar Middle





Terrawagen Rear Inner door trim kit

Installation instructions:

Thanks for buying our products!

Kit contents: 3 rear door trim covers, hardware pack, Jelly beans.

These parts in this kit are bigger than they need to be on purpose. Because every builder is unique we have made the parts longer on the wall side so you can cut them to fit your particular wall and ceiling thickness.

Notes on cutting ABS plastic:

ABS plastic can be scored with a box knife multiple times and it will break on the score. It can also be cut with traditional saws. Bandsaws work well, Jig saws also. Edges can be sanded or filed. We also suggest de-burring freshly cut edges prior to covering in upholstery.

We include 10 M6 rivnuts in the kit. 4 of them are used on the ceiling cap area. Drill out the factory holes to 9mm using the supplied drill bit.

Uprights: 2 of the existing holes in the sheet metal are pre-threaded with M8 nuts. Look at our upright parts and you can match where the supplied rivnuts will go. Drill out the factory holes and set the rivnuts.

* Cutting, filing and sanding will be required for YOUR specific fit.

